

PIECE OF CEMCO STUD OR
TRACK WEB STIFFENER,
3/8" SHORTER THAN DEPTH
OF JOIST AS REQUIRED BY
BUILDING CODE OR E.O.R.

CEMCO SSCJ FLOOR JOISTS
PER PLAN

(1) #10-16 SCREW
TOP FLANGE AT EACH
JOIST

ATTACH BACK-TO-BACK
CEMCO SSTM RIM-TRACK
AS REQUIRED BY
BUILDING CODE OR E.O.R.

SCREW ATTACH,
WEB STIFFENER TO
JOIST (BY DESIGN)

ATTACH RIM-TRACK
TO TOP OF WALL AS
REQUIRED BY BUILDING
CODE OR E.O.R.

3 1/2"
MIN
10" MIN,
TYP.

CONCRETE/MASONRY/
INSULATED CONCRETE
FORMS (ICF) WALL
(BY OTHERS)

